



1967 S Style Tail Lamp Kit Installation Instructions



First, remove product from packaging and make sure you have all of the items necessary.

Kit Includes: 6ea bulb socket pigtails, 1pr of lenses, 1pr of light housings, 1pr of tail light bezels, 1pr of gaskets and studs for mounting the bezel.

We're assuming you already have the 67 S Sytle tail light panel installed. If not, use the 67 tail light panel to scribe and cut the hole in your original tail light panel.

Step 1 – Unhook the battery.

Step 2 - Use the mounting studs provided and install them into the bezel/tail light frame.

Step 3 - Hold the bezels with the pre-mounted studs, up to the opening on the fiberglass panel and mark the holes to be drilled. The arrow like point should face inward. These should be drilled long enough to penetrate the original metal panel. Drill holes with a 1/8" drill bit. Put the bezels in place in the tail panel.

Step 4 - The plastic bezels have a pointed side, this side points inward. The lens gasket and lens should be held together to the plastic housing prior to putting it through the hole in the tail panel. Slide the pre-assembled lens and housing assembly over the studs of the tail light bezel, attach nuts and a tighten.

Step 5 – Insert 1157 bulbs into the light sockets, and install them into the light housings. Connect all the brake lights and running lights together on each side. Use the ground loop to attach to a good ground on the body. Test the lights by hooking up the battery and depressing the brakes.

Happy Mustangin'