



INSTRUCTIONS

PN: FD5032

05- 09 MUSTANG GT UPPER NO LOGO POSITION .

Hardware

4-- Bolts 4-- Flat tabs 4-- Nuts 4-- "K" nuts 4--Screws

NOTE: Be Careful not to scratch the grills Surface.

Step1.0--Remove the plastic radiator cover from the vehicle, Test fit the grills over the factory grille. The side billet will only fit one way.

Step2.0--Cut out the pony position on factory grille shell.

Step3.0--Mark on the plastic grille base our new billet grille weld holes. Drill a hole at each mark; Use the screws and "K" nuts to secure the billets.

Step4.0--Center each billet grille into opening grille shell, insert the bolts into the tabs of grille and plastic shell, place the tabs and nuts; tighten them. Snug the hardware down until the billet is held firmly in place.

Step5.0--Re-install the plastic radiator cover.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!

2510 E Sunset Rd Suite #3 Las Vegas, NV 89120

Phone (702) 262-0011 or Fax (702) 262-0099